Connecting Sensors

Installation & Reference Guide for Installers


Procedure

- 1. Perform the initial installation.
- 2. Move to this guide for the sensor/input installation


Installation Instructions

- If you did not insert the bridge harness during installation, do it now.
- Identify the output of the device or sensor to be monitored.
- Using a DMM, check to see if the output is (+) or (-) when activated.
- Proceed as follows in using Guide (1) or Guide (2).
- The MC4 input needs to see (+) voltage. The single input will be marked.

Guide (1): Using a relay



Guide (2): Direct Connection



Technical support can be reached at 855-544-6218.

<u>Disclaimer:</u> All information is provided as a resource for the installer. Any installer and/or user of this document assumes the entire risk as to the accuracy and use of this information contained. Please verify all wire colors, diagrams, and documentation before applying any information. Always use a digital multi-meter when testing wires/circuits. [R 02.23A]

