


## Prime Pod

Hardware Guide

Expanded View	2
Top/Bottom View	3
Quick Start Guide	4
SIM Card Installation	.5
Battery Replacement	6,7











## **Quick Start Guide**





Have mounting bracket and device ready.




Once unlocked, pull cover off device.



Use the USB C port located on the side of the device (under the ON/OFF switch) for programming device commands.



Connect top of bracket with the slots on the bottom of the Pod.




Locate the power switch on the side of the device and slide it to the "ON" position.



Put the cover back on the device.



Twist the bracket counterclockwise to unlock the top cover.



Wait for the LED light to turn on.



Use the bracket (step 1) to twist the device clockwise to lock it.

## SIM Installation Guide






Have mounting bracket and device ready.




Once unlocked, pull cover off device.



Slide tray cover to unlock, open and insert the new SIM card with the gold contacts facing down.



Connect top of bracket with the slots on the back of the device.




Locate the power switch on the side of the device and slide it to the "OFF" position.



Close and lock the SIM card tray by sliding it forward, then turn on the device after installing new SIM card.



Twist the bracket counterclockwise to unlock the top cover.



Locate the SIM tray on the top of the device.



Use the bracket (step 1) to twist the device clockwise to lock it.






Connect top of bracket with the slots on the bottom of the device.



Twist counterclockwise to unlock the top cover.



Once unlocked, pull cover off the device.



Twist counterclockwise to unlock center component from base.



Once unlocked, pull component out of the case.



With the battery facing up, pull out old battery and unplug from device.





Connect new battery and put into device.



If Pod has sensors, align sensor hole on case with sensor hole next to battery.



Twist device clockwise, interlocking teeth on base with threading on component, until it makes a clicking sound.



Ensure the embossed guide arrow on side of device lines up with corresponding arrow on rim of the base.



Plug device into a computer using the USB C port and send battery replacement command (AT+GTRTO) via Micron MAP Utility program. Reset device after command acknowledged.



Put the cover back on device. Use the bracket (step 1) to twist device clockwise to lock it.